

neodisher[®] brilliant dry

Rinsing agent for use in dishwashers



Main fields of application:	Use for rinsing dishes of all types in dishwashers.
Characteristics:	<p>neodisher brilliant dry is a highly concentrated rinsing agent with citric acid, for a particularly good clear rinse effect with china, stainless steel, silver and silver-plated cutlery, and glassware.</p> <p>neodisher brilliant dry is particularly suitable for dishwashers in which the widest possible variety of dishes etc. are washed and clear rinsed. neodisher brilliant dry is also very suitable for short-programme dishwashers in the catering trade and in hospital wards.</p>
Application and dosage:	<p>Use in dishwashers: 0.1 - 0.8 ml/l in the final rinse water.</p> <p>neodisher brilliant dry is added to the last rinse water from the dispenser in the machine. The dispenser must be adjusted to the prevailing water hardness and to suit the type of articles being washed. The dosage preset by the machine manufacturer is generally satisfactory. The dispensing system must be acid-resistant for use with neodisher brilliant dry.</p> <p>Do not mix with other products.</p> <p>For professional use only.</p>
Technical data:	<p>Specific gravity: (20 °C): 1.05 g/cm³ pH-range (determined in deionised water, 20 °C): 0.1 - 0.8 ml/l: 4.3 - 3.6 Viscosity (concentrate, 20 °C): < 50 mPas</p>
Ingredients:	<p>Ingredients according to Regulation (EC) No 648/2004 on detergents: < 5 % phosphonates 15 - 30 % non-ionic surfactants also preservatives (Methylchloroisothiazolinone/Methylisothiazolinone)</p>
Storage information:	The product is sensitive to frost.
Hazard warnings and safety advice:	<p>neodisher brilliant dry has not to be classified according to the Dangerous Preparation Directive 1999/45/EC.</p> <p>If applied according to the instructions for use the product is safe in the sense of the appropriate guidelines upon food processing.</p> <p>Dispose only when container is empty and closed. For disposal of product residues, refer to Material Safety Data Sheet.</p> <p>For further safety information see EC-Safety data sheets. These are available e.g. under www.drweigert.de under the headline "Service".</p>

MB 3501 GB/2-1
12/05



Chemische Fabrik Dr. Weigert GmbH & Co. KG
Mühlenhagen 85, D - 20539 Hamburg

Telefon: (040) 789 60 - 0
Telefax: (040) 789 60 - 120

E-Mail: info@drweigert.de
Internet: www.drweigert.de

Die Angaben dieses Merkblattes beruhen auf unseren derzeitigen Kenntnissen und Erfahrungen. Sie befreien den Verwender nicht von eigenen Prüfungen und Versuchen. Eine rechtlich verbindliche Zusicherung bestimmter Eigenschaften kann hieraus nicht abgeleitet werden.

With the above information, which is appropriate to our current knowledge we describe our product regarding possible safety necessities, but we do not involve any quality description or promise certain properties.