

neodisher® BioClean Pulver

Enzymatic cleaning agent in powder form
for use in dish-washing machines



Main fields of application: Use in dishwashers for china, stainless steel, aluminium, silver and plastic ware in hospitals, old peoples homes, nursing homes, bulk catering establishments, the catering trade and hotels.

Characteristics: neodisher BioClean Pulver is an enzyme-based detergent with cleaning-enhancing dispersants and special wetting agents. In addition to the very gentle action, neodisher BioClean Pulver is characterised by its high cleaning power.

neodisher BioClean Pulver is
• **chlorine-free** • **non-corrosive** • **non-irritant**

and, in contrast to conventional (alkaline) detergents, significantly improves the room atmosphere in the cleaning area.

Application and dosage: Use in dishwashers:
2 - 5 g/l (manual or using suitable powder metering equipment), 60 - 70 °C with tank machines, top up after 5 - 10 loads.
Subsequently the neodisher BioClean Pulver-solution has to be rinsed out completely by sufficient rinsing. Do not mix with other products.
Do not mix with other products.

Technical data: Bulk density: 975 - 1.025 g/l
pH-range (determined in deionised water, 20 °C) 2 - 5 g/l: 9.0 - 9.5

Ingredients: Ingredients according to Regulation (EC) No 648/2004 on detergents:
< 5 % non-ionic surfactants
> 30 % phosphates
außerdem Enzyme

Environmental aspects: In machine washing of crockery at tank temperatures between 60 and 70 °C achieves not only optically but also hygienically clean dishes coupled with the greatest possible care and, in contrast to conventional (alkaline) detergents, significantly improves the room atmosphere in the cleaning area. The use of neodisher BioClean Pulver is generally recommended in those cases where both a high level of personal protection as well as discharges with a pH in the neutral region are required.

Storage information: Do not store above 30 °C. Keep containers tightly closed. The product is sensitive to moisture. Usable for 1 year when stored as recommended.

Hazard warnings and safety advice: neodisher BioClean Pulver has not to be classified according to the Dangerous Preparation Directive 1999/45/EC.

If applied according to the instructions for use the product is safe in the sense of the appropriate guidelines upon food processing.

Dispose only when container is empty and closed. For disposal of product residues, refer to Material Safety Data Sheet.

For further safety information see EC-Safety data sheets. These are available e.g. under www.drweigert.de under the headline "Service".

MB 3217 GB/2-2
08/05



Chemische Fabrik Dr. Weigert GmbH & Co. KG
Mühlenhagen 85, D - 20539 Hamburg

Telefon: (040) 789 60 - 0
Telefax: (040) 789 60 - 120

E-Mail: info@drweigert.de
Internet: www.drweigert.de

Die Angaben dieses Merkblattes beruhen auf unseren derzeitigen Kenntnissen und Erfahrungen. Sie befreien den Verwender nicht von eigenen Prüfungen und Versuchen. Eine rechtlich verbindliche Zusicherung bestimmter Eigenschaften kann hieraus nicht abgeleitet werden.

With the above information, which is appropriate to our current knowledge we describe our product regarding possible safety necessities, but we do not involve any quality description or promise certain properties.